

Curing of the COLORiT Smear Layer with Glycerin

Cured COLORiT pieces can be immersed in warm glycerin and light-cured for another few minutes to cure the "smear layer" resulting in a lustrous polished surface.

1. Apply COLORiT and cure your ring (or other item) normally.
2. Do *not* remove the smear layer.
3. Fill a small glass container with liquid glycerin (available from your local pharmacy). The glass jar should be large enough to hold your ring but not much larger. Pour in enough glycerin so that the ring can be completely submerged.
4. Heat the glycerin to approximately 140° F. (60° C.). You can use your COLORiT heated work plate for this purpose: place the glass jar with glycerin on top of the work plate for about 10 minutes.
5. Position the COLORiT light close to the side of the glass jar and turn it on. Make sure light is angled away from your eyes.
6. Immerse the ring in the glycerin and, keeping it as close to the light as possible, slowly rotate it for 1 to 2 minutes until the surface is cured.

If using COLORiT Power: Immerse the ring in the glycerin and place the jar into the COLORiT Power for 5 minutes or until surface is cured.

This procedure will cure the smear layer leaving a polished surface. You can treat this surface as you would any normal COLORiT surface.